


GoPro Hero 9/10 BLACK Kneeboard Checklist

- **GoPro Camera**

- Looking at the front of camera, unlatch the left side panel from the side bottom, pull down, swing out.
- Insert/remove both battery and memory card.
- Push power button on right side.
- Open mount from bottom, attach a mounting extension.



- On rear LCD display, swipe down, then swipe left and tap on **Preferences** then **Format SD Card**.
- In iPad Quik app:
 - Click on Preference icon, then bottom **Time Lapse button**, then TimeLapse **pencil**.
 - Select: Lens=**Linear**, Interval=**5s**, Format=**Time Lapse Photo**, Output=**Standard**, Duration=**No Limit**, Timer=**Off**.
 - Tap the **red** timer button to begin the GoPro recording.
 - Display will show # of photos taken.
- Start camera record when in target area (note time).
- Stop camera record when exiting target area (note time).